


S4 Beam Sensor & brackets

(for Vigilon and Nano Systems)




Transmitter (red retainer) Receiver (black retainer)


- ☐ Beam sensor pair (Transmitter & Receiver)
S4-34740
- ☐ Beam Transmitter only
S4-34741
- ☐ Beam Receiver only
S4-34742



- ☐ Angle bracket with base
S4-34741-01



- ☐ Parallel bracket with base
S4-34741-03



- ☐ Light Shield (5 per pack)
S4-34741-99

Test Cards
S4-34741-50

The Beam Sensor pair allows the detection of smoke over distances from 2 m to 100 m, using a 'beam transmitter' and a 'beam receiver', each mounted on a base fixed to either bracket.


Technical Data

Standards - designed to meet	EN54 : Part 12 : 2002 EN54 : Part 17 : 2005			
Approvals	LPCB Approved STATES 0, 1, 2 and 3			
Overall assembled dimensions in mm	Transmitter or receiver: Ø 117 x d 54 Angle bracket with base: h 145 x w 106 x d 130 Parallel bracket with base: Ø 152 x d 27 Light shield: Ø 50 x 75			
Assembled weight (approximate)	Transmitter or receiver:105g Angle bracket + base: 620g Parallel bracket + base: 600g Light shield: 14g			
Enclosure	ABS			
Colour (Sensor)	RAL9010			
Storage temperature	-20 to +70°C			
Ambient operating temperature	-10 to +50°C			
Relative Humidity (Non condensing)	up to 95% Temperature +5 to +45°C			
Emission	BS EN61000-6-3: 2007 EMC for residential, commercial & light Industry.			
Immunity	BS EN50130-4: 1996 + A1:1998 +A2 2003 for alarm systems			
Ingress Protection (estimated)	IP30 IP20 mounted on bracket			
Operating voltage	35-41V			
Indicators	Two Red and Seven Green LEDs visible at 500LUX ambient light levels 5m			
EN54-17 : 2005 (section 4.8) data:	V _{max}	42V	I _C max	0.4A
	V _{nom}	40V	I _S max	1A
	V _{min}	24V	I _L max	20µA
	V _{SO} max	16V	V _{SO} min	8V
	Z _C max	0.130Ω		
Compatible Backward compatibility is possible, refer to your supplier	Vigilon : MCC ≥ V4.41 / V3.96 LPC ≥ V4.39 / V3.96 Nano : MC ≥ V1.39 LD ≥ V1.03			


Do's and Dont's

A general guidance on Do's and Dont's is illustrated here, however for full information on siting beam sensor pair refer to BS5839 Part 1.



IR Beam projection




Solid Wall





Metal beam





Obstructions





Side view (flat ceiling)



Plan view (flat ceiling)




Plan view (flat ceiling)



Test Keyswitch

A test keyswitch unit can be connected to the 'beam transmitter' to facilitate simulation of a test fire condition. The test keyswitch function is supported on Vigilon system only. The keyswitch unit is required to have a series resistor of value 470Ω coupled with an end-of-line $10K\Omega$ resistor wired as illustrated below.



There is a maximum cable length limit of 15 metres from the 'beam transmitter' base to the external Keyswitch Unit.


A keyswitch input at the 'beam transmitter' must be enabled during commissioning.

The wiring is monitored for open and short circuit failure.

On operating the keyswitch it will cause a ramp down signal to generate a test fire condition.


How to install an Angle bracket and fit a Beam sensor

The installation of the angle bracket and beam sensor are illustrated by steps ① to ⑥. Note steps ⑤ and ⑥ require setting of adjusters for sensor to face the opposite sensor assembly, which is normally done during commissioning.




How to pre-assemble the parallel bracket

The parallel bracket may be pre-assembled as illustrated by steps ① to ④.




How to install a Parallel Bracket and fit a Beam sensor

The installation of the parallel bracket and beam sensor are illustrated by steps ① to ⑧.



Further information about this product can be found in Part 2 of this document available on Gent Expert website.



Gent by Honeywell reserves the right to revise this publication from time to time and make changes to the content hereof without obligation to notify any person of such revisions of changes.

GENT
by Honeywell

Hamilton Industrial Park, Waterside Road, Leicester LE5 1TN, UK

Telephone: +44 (0) 116 246 2000

Tech. Support: www.gentexpert.co.uk

Website: www.gent.co.uk

Fax (UK): +44 (0)116 246 2300

Commissioning information

S4 Beam Sensor & brackets

(for Vigilon and Nano Systems)

G E N T
by Honeywell

This document describes how to adjust the beam sensor using adjusters on the angle or parallel bracket, align beam sensor pairs and test the installation.



Transmitter (red retainer) Receiver (black retainer)
A beam sensor pair consist of a:

- ☐ 'beam transmitter' that can be identified by a **red** lens retainer and a
- ☐ 'beam receiver' that can be identified by a **black** lens retainer.
- ☐ each sensor is fitted onto a base that is a part of an angle or parallel bracket.

Compatibility

The S4 Beam Sensor pair are compatible for use in Vigilon and Nano systems having the following panel firmware.


Control Panel	having card and firmware
Vigilon	Main Controller Card ≥ V4.41 / V3.96
	Loop Processor Card ≥ V4.39 / V3.96
Nano	Main Controller ≥ V1.39 Loop Driver ≥ V1.03

Backward Compatibility

An S4 Beam sensor pair can be converted to be a BACKWARD COMPATIBLE Beam Sensor pair.


The conversion is done using a Programming base interface for S4 beam sensor pair, see section headed 'Backward Compatibility'.

Commissioning checks




How to align a Beam Sensor pair

Overall process to align Beam sensor pair



During the alignment process all the LEDs on the 'beam transmitter' and 'beam receiver' act as a simple level meter to indicate the ADC bit level. An increase in level causes the intensity of the particular LED to increase, until the level is enough to turn on the next LED to the right.



Make adjustments in the X axis and Y axis, using adjusters on the beam sensor bracket to let the highest Green LED to illuminate. The LEDs update every 2 seconds, so make small adjustments and wait for the indication to refresh.


The illumination of red LEDs on a beam sensor will indicate the level is either too low or too high and it is important to carry out a sensor **[Auto Gain]** after adjustment of the bracket.




On first power up of the system having beam sensors a light indication of 'Sensor out of Specification' is given at each beam sensor, with the left most Red LED on the beam sensor lit.

- Assuming the beam sensor pair are in rough alignment at the control panel activate the **[Autogain]** function on the '**beam receiver**' of the beam sensor pair to be commissioned. You will need to know the device address of the 'beam receiver' and the loop number on which it resides.

Procedure for Vigil panel (Access level 3)




Procedure for Nano panel (Access level 4)




- Using the options in **[Test/Eng]** menu put the required beam pair into **[Align]** mode.


Procedure for Vigil panel (Access level 3)




The alignment function will timeout after 1 hour.

Procedure for Nano panel (Access level 4)

- ③ Using the adjustments at the bracket of the '**beam transmitter**' align this device with the '**beam receiver**' and obtain a best bit level indication by getting an illumination of the highest green LED.



- ④ To auto gain at the device **press and hold** on the **Autogain button**. This will actually perform an autogain on the '**beam receiver**' of the beam sensor pair. At the device all the LEDs turn off and after a delay the green LEDs indicate the new ADC bit level. If necessary make further bracket adjustment and perform an autogain again by a **press and hold** of the **Autogain button** on the device.



- ⑤ Using the adjustments at the bracket of the '**beam receiver**' align this device to face the '**beam transmitter**' and obtain a best bit level indication by getting an illumination of the highest green LED.

- ⑥ Auto gain at the device by a **press and hold** of the **Autogain button**. At the device all the LEDs turn off and after a delay the green LEDs indicate the new ADC bit level. If necessary make further bracket adjustments and perform a further autogain by a **press and hold** of the **Autogain button** on the device.


- ⑦ Finally perform an **Auto gain** at the '**beam receiver**' using the **PANEL CONTROLS ONLY**. After performing an auto gain at the panel the green LEDs will turn off.

Now move on to align the next beam sensor pair by carrying out procedures ① to ⑦ above.


Brackets

How to adjust the Parallel bracket

To adjust the parallel bracket follow these procedures:



Ensure the lock nuts are opened out.




To tilt the 'adjustable plate' in the 'Y' axis towards the bottom:
In small movements unscrew the **top Y adjuster** ①
and at the same time screw down the **bottom Y adjuster** ②




To tilt the 'adjustable plate' in the 'Y' axis towards the top:
In small movements screw down the **top Y adjuster** ①
and at the same time unscrew the **bottom Y adjuster** ②

On completion secure the adjustment by the two **lock nuts Y**, using a 7mm nut driver.



To tilt the 'adjustable plate' in the 'X' axis towards the left hand side:
In small movements screw down the **left X adjuster** ③
and at the same time unscrew the **right X adjuster** ④



To tilt the 'adjustable plate' in the 'X' axis towards the right hand side:
In small movements unscrew the **left X adjuster** ③
and at the same time screw down the **right X adjuster** ④


On completion secure the adjustment by the two **lock nuts X**, using a 7mm nut driver.



Hold the **adjuster** in place to prevent movement while it is being locked to retain the setting.

How to adjust the Angle bracket

The bracket shown is without the sensor fitted for clarity



To adjust the angle bracket follow these procedures:

- Slacken both 'Y' adjuster **lock nuts** on the bracket and then unscrew the '**Y**' adjuster screws.
- Adjust the base in the 'Y' axis to roughly face the opposite beam sensor bracket assembly.
- Where a large angle adjustment is required, then it may be necessary to move the **pivot stop** from the '**Y**' Pivot and fit it in the appropriate screw hole on the 'Y' pivot to assist alignment.
- Once the base is facing the opposite beam sensor bracket secure this position by locking the **pivot stop** using the '**Y**' adjuster screws.
- Now secure the '**Y**' adjuster screws by their **lock nuts**. To do this ensure each '**Y**' adjuster screw is locked in the set position by its **lock nut** to prevent movement of adjuster screw.
- Similarly make adjustments in the 'X' axis using the 'X' adjuster screws and lock the settings using the lock nuts.

Alignment Angles

The table below shows the maximum misalignment angles at the medium sensitivity setting of 25% (and the default sensitivity of 50%).


	Transmitter	Receiver
Measurable signal during installation	± 3 degree	± 5 degree
Maximum movement after installation	± 1 degree (± 2)	± 2 degree (± 3)
Movement claim for EN54-12	± 0.5 degree	± 1 degree

Light Shield

How to fit a Light Shield

A 'light shield' must only be fitted to the 'beam receiver' to prevent sunlight or strong light affecting signals received at the 'beam receiver'.


- ① Align the 'light shield' with lens retainer on the 'beam receiver'.
- ② Press the 'light shield' onto the 'lens retainer' of the 'beam receiver' until it locks into place, a 'click' sound can be heard when there is a positive lock.



Indicators

How to interpret operational indications at a Beam sensor

The two red end LEDs on a beam sensor provide Working indication, Fire indication, Device found indication.



	Description	Indicates
Flashing	On the 'beam receiver' only	FIRE Event
Continuous Long flashes	On the 'beam receiver' or 'beam transmitter'	Found device
Frequent Short flashes	On the 'beam receiver' or beam transmitter' (The working indication is optional and must be set at the commissioning tool)	Device working



Find Device

How to find a 'Beam receiver' or 'Beam transmitter'



You can find a 'beam transmitter' or 'beam receiver' device on a loop circuit by using the **Find Device** function at the control panel.

To speed up the search to find the location of a Beam sensor you must first refer to the '*as fitted wiring drawings*' which provides the address or approximate address of the device on the loop circuit. Enter the device address at the panel and **[Start]** the 'find device' function. When the beam sensor is found then its red LEDs flash.

Procedure for Vigilon panel (Access level 3)



Procedure for Nano panel (Access level 4)



Beam sensor STATES

The Beam Sensor is designed to operate in any one of the following sensor STATES.



Do not use beam sensor STATES that are not listed below, as selecting an UNUSED STATE will be interpreted by the panel as STATE 0.

States verses distance

Sensor STATES	Ideal range minimum to maximum
4 or 5	2m to 30m
2 or 3	5m to 100m
0 or 1	12m to 100m

LPCB approval

The Beam sensor STATES 0, 1, 2 and 3 are approved test at LPCB.

Beam Sensor STATES

STATES	Definition	Application
STATE 0	Default detection	A fire is detected when there is a 50% (3dB) fall in signal level, however if the fall is by 90% (10dB) in less than 1second and is maintained for 40 seconds, then a fault is registered. This allows the Control panel to differentiate between a fire and a fault signal caused by accidental obscuration.
STATE 1	Normal sensitivity	A fire is detected when there is a 50% (3dB) fall in signal level, however if the fall is by 90% (10dB) in less than 1 second and is maintained for 40 seconds then a fire is registered.
STATE 2	Medium Sensitivity	A fire is detected when there is a 25% (1.3dB) fall in signal level, however if the fall is by 90% (10dB) in less than 1 second and is maintained for 40 seconds then a fault is registered.
STATE 3	Medium Sensitivity	A fire is detected when there is a 25% (1.3dB) fall in signal level, however if the fall is by 90% (10dB) in less than 1 second and is maintained for 40 seconds then a fire is registered.
STATE 4	High Sensitivity	A fire is detected when there is a 10% (0.5dB) fall in signal level, however if the fall is by 90% (10dB) in less than 1 second and is maintained for 40 seconds then a fault is registered.
STATE 5	High Sensitivity	A fire is detected when there is a 10% (0.5dB) fall in signal level, however if the fall is by 90% (10dB) in less than 1 second and is maintained for 40 seconds then a fire is also registered.
STATE 15	No detection.	This is a total disablement of the sensor.


How to set up a Beam sensor STATE

The Beam Sensor is factory set to operate at **STATE 0**. To configure the beam sensor to operate in a different STATE you will need to change the device setup of the '**beam receiver**'.


The STATE setting of a 'beam receiver' is usually done during commissioning of the system using the **commissioning tool**, however it is possible to use the panel menus to change the sensor operating STATE. Enter the required STATE number for both *Enable (Day)* and *Disable (Night)* time periods.

You will need to know the 'beam receiver' device address and loop number on which it is installed.

Procedure for Vigilon panel (Access level 3)



Procedure for Nano panel (Access level 3)




Time averages

How to read the time average values of a beam sensor


Where two people are available for commissioning beam sensor pairs, then it may be appropriate to view the time average readings to get the best bit value setting during fine adjustment.

Procedure for Vigilon panel




Obtain the highest bit reading (between 140 - 180) for optimum alignment.

Select **[Repeat]** to refresh the display with the latest values.



Procedure for Nano panel (Access level 4)



Obtain the highest bit reading (between 140-180) for optimum alignment.

Select **[Update]** to refresh the display with the latest values.

How to view the 'Status' of a Beam sensor and check the set Gain value

The Gain value read from 'beam receiver' device status should approximately correspond to the value in the *table* for typical distances between the 'beam transmitter' and 'beam receiver'.

Distance between beam transmitter and receiver (path length)	2m	6m	10m	15m	20m	30m	45m	60m	70m	80m	90m	100m	110m	120m
Gain Value (± 4)	6	19	25	33	38	41	44	46	47	49	51	53	55	56



If a beam sensor pair path length is greater than 100m then the requirements of EN54: Part 12 will not be met.

[illegible]

The diagram illustrates the navigation flow from the Menu to the Settings screen, then to the Select screen, the Loop screen, the Select screen, and finally to the Devices screen. Below this, two screens are shown: 'Beam Receiver' and 'Beam Transmitter'.

Beam Receiver

Device: [24] Settings 16:48 Mon 23/02/09
 Label: [Device Label Find: [OFF]
 Type: Beam Receiver
 Assigned to Zone: [1]
 Sensitivity States Night: [0] Day: [0]
 Gain: [63]
 Save Quit

This example shows a Beam receiver Gain value of 63

Beam Transmitter

Device: [25] Settings 16:59 Fri 26/04/08
 Label: [Device Label Find: [OFF]
 Type: Beam Transmitter
 Save Quit


Test

How to test a beam sensor pair



After all the beam sensor pairs are fully commissioned use the appropriate test card (S4-34741-50) to obscure the beam to simulate a FIRE or FAULT condition.

If a **Test Keyswitch** unit is connected to a 'beam transmitter' of a beam sensor pair then, if appropriate, operate the switch to test the beam sensor pair. A test using a Test Keyswitch is not applicable for S4 beam sensors converted to be backward compatible.

STATE	FIRE test using a test card	FAULT test using a card
0	Use the 50% obscuration Test card in the beam path	Use a piece of cardboard to block the beam path for 40 seconds
1	Use the 50% obscuration Test card in the beam path Use cardboard to block the beam path for 40 seconds	N/A
2	Use the 25% obscuration test card in the beam path	Use a piece of cardboard to block the beam path for 40 seconds
3	Use the 25% obscuration test card in the beam path Use a cardboard to block the beam path for 40 seconds	N/A



A fire indication is given at the '**Beam receiver**' only and not at a 'Beam transmitter'. Also a fire indication is given at the panel.



Commissioning tool

Vigilon - Commissioning tool

The S4 Beam sensor pairs connected to the loop circuits of a Vigilon panel be configured using Commissioning tool ($\geq$ V1.26). Ensure the 'working indicator' operation and 'monitoring type' are correctly configured for each beam sensor pair.

Menu selection

1a Configuration

1b Beam Config.

Icon selection

1

Beam Configuration

Beam List:

- L1 Dev 6 - Beam Tx
- L1 Dev 7 - Beam Rx

☒ Working Indicator

Monitoring Type: Monitored test input

Last Changed: 27/02/09

OK Cancel

2 Select a beam sensor from the list

3 Check the working indicator box if required. (The factory default is unchecked, ie working indication is not given)

4 Select the monitoring type which is applicable for the 'beam Transmitter' only. The options include:
☐ Unmonitored repeat LED
☐ Monitored test input

Monitored test input must be selected for 'beam transmitter' having a Test Keyswitch connected to its base.

5

The selected device in the beam list had its settings changed the last time on the date shown here.

L1 - loop circuit 1
 Dev 6 - device number 6
 'Beam Tx' - is the device label

Nano - Commissioning tool

The Nano Commissioning tool V1.2 does not allow for 'working indicator' operation and 'monitoring type' functions.

Backward compatibility

The **S4 Programming tool** (S4-BASE-PROGRAM) and **S4 Programming Base Interface for S4 Beam sensor pair** software is used to convert an S4 Beam Sensor pair to be compatible with the older type 34740 Beam sensor pair.



1. You will need to program **BOTH** S4 beam transmitter and S4 beam receiver for backward compatibility.
2. When installing a backward compatible S4 beam sensor pair to replace an existing 34740 beam sensor pair you will also need to replace the brackets, use either S4-34741-01 (angle bracket) or S4-34741-03 (parallel bracket).
2. The monitored test input for test fire is **NOT** applicable on a S4 beam sensor pair that is made backward compatible.
3. The sensor working indicator function on the backward compatible S4 beam sensor pair is **NOT** applicable.
4. The Autogain function button on a backward compatible S4 beam sensor pair is **NOT** applicable, use instead the Autogain function at the Control panel.

How to determine backward compatibility of S4-34740 Beam Sensor pair

Type 3 S4-34740 Beam Sensor pair




Before converting the S4-34740 beam sensor pair (Type 3) to a backward compatible beam sensor pair, check the type of beam sensor build installed in your system to ensure it is supported to accept a backward compatible S4-34740.




Supported Type 2 Beam Sensor pair build
With panel having
Local Controller Card & Loop Processor Card:
☐ BS version equal to or greater than V3.40
☐ EN version equal to or greater than V4.00

Not Supported Type 1 Beam Sensor pair build

How to connect the S4 Programming tool and how to fit a beam sensor to the tool



⚠ Damage will occur if you fail to align sensor markings to the markings on the programming base ①.



S4 Beam Programming Base Interface software

The S4 Beam programming base interface application can be downloaded from Gent Expert (<http://gentexpert.co.uk/>). Once the software is downloaded onto your computer simply **Run** the **setup.exe** of the application.

The installation of software will check to see if the computer has **.netframework 3.5 with Service pack 2** installed and will automatically install these from the internet if the computer is connected to the internet.



Allow sufficient time for the installation of .netframework 3.5 with Service pack 2, as this will take several minutes.


How to change the mode of an S4 Beam Sensor pair

Using this programming tool and software application on your laptop you can change an S4 beam sensor pair to be backward compatible with 34740 beam sensor pair. The tool also allows conversion from a backward compatible S4 beam sensor back to its original factory set mode.



- Ensure the S4 beam sensor is correctly and securely fitted into the programmable base. Connect the power and communication leads to the programmable base and computer as shown, then switch ON the mains power. Note the outside LEDs on the Beam sensor will flash on power up.
- Click on the **S4 Programming Base Interface** icon on your desktop to run the application.



- Click on the *S4 Beam* tab.



- The *Device information* ① and *Operating mode* ② will provide a message once the device fitted to the Programming base is detected.
 - The *Device information* ① will always read 'S4 Beam Mk II V1.00 19/05/09'
 - An original S4 beam sensor device will show its *Operating mode* as:
 - 'S4 Beam mode - Active' ②.
 - A Backward Compatible S4 Beam sensor will show its *Operating mode* as:
 - 'Backward compatible Beam sensor - Active' ②.
 - Select the *Change mode* button ③ to switch the S4 Beam Sensor mode.
 - The *Status message* ④ will initially read '**Waiting for write confirmation**' and on completion of the configuration it will read '**eeprom write completed**' followed by a green checkmark icon ⑤ to the right of the *Change mode* button ③. The *Operating mode* will show the respective compatibility message. A cross at ⑤ indicates failure to convert the beam sensor, so power down the programming base, remove the beam sensor from base and repeat steps a. to f. There is no need to power down the programming base to program the next beam sensor.

[illegible]

GENT
by Honeywell

Fax (UK): +44 (0)116 246 2300