

Installation Instructions

Repeat panel back box

1st Fix

The Repeat Panel Set consists of three packages:

- 1st fix package: Repeat Panel back box
- 2nd fix package: Inner door, moulded door, master repeat card, instructions and spares pack
- 3rd package: Battery
1 - 12V 7Ah

The **repeat panel** can be **surface or flush** mounted.

The following instructions are for the 1st fix package. The 2nd fix package and 3rd package are installed during the commissioning stage.

Fuses and location

Fuse	Rating	Location
Mains	3.15A AS	Top right of back box

Surface or flush the repeat panel

- a Identify the Repeat panel back box package and remove the temporary cover from the back box.
- b Secure the back box to the wall with suitable fixings. If flush mounting use the flush surround.
- c Terminate the cable at the entry point leaving **400mm** tail wire length.



If mains cable is not connected then ensure the mains cable tail ends are insulated to guard against accidental switching ON of the mains supply.

- d Refit the temporary cover to protect the panel until commissioning.



