


# Vigilon panel - Sound and Resound alarms options


## Resound [FIRE] -> ON / OFF setting

The FIRE ON/OFF setting under [Resound] controls the way sounders operate when a 2nd or subsequent fire occurs after the alarms have been silenced following 1st fire.




## Resound [SOUND] -> ON / OFF setting

The SOUND ON/OFF setting located under [Resound] controls the way sounders operate on 1st press of the Sound Alarms button during a fire condition after the alarms have been silenced. When set to ON the sounders will resound and when set to OFF the sounders will perform the standard action of all-out alarms.




## Resound Delay mode function

There are 4 control settings for Delay mode under [Resound]. These settings control what happens to the delay blocks when the Silence Alarms button is pressed.




Resound DELAY MODE setting


[STOP]



[PAUSE]



[TIME]



[ACTION]

